



Hotel & Restaurant Service



Mesh – Teil | Part 1/6

Mesh ist eine innovative Dining- und Gourmetkollektion mit vielen variabel einsetz- und kombinierbaren Einzelteilen, z.B. für Tapas und Buffets. Ein zartes Gitterrelief macht die klaren, geometrischen Formen der Kollektion besonders lebhaft und modern. Die modernen Farbtöne Aqua, Cream und Mountain betonen perfekt die außergewöhnliche Struktur der Mesh Kollektion.

Durch die hohe Brenntemperatur von 1400°C schmilzt die spezielle Farbglasur in das Porzellan ein und lässt so auf jedem Teil einzigartige Farbverläufe entstehen. Mesh Colors steht für Modernität und lässt sich wunderbar kombinieren.

Mesh is an innovative dining and gourmet collection with many variably usable and combinable individual pieces, e.g. for tapas and buffets. What makes the well-defined geometric forms of the Mesh collection really special is the delicate, bamboo like Mesh relief. The modern color glazes Aqua, Cream and Mountain perfectly accentuate the beautiful texture of the Mesh collection.

Thanks to high firing at 1400°C, the special colored glaze melts into the porcelain and creates unique shades on each piece. Mesh colors reflects modernity and inspires new elegance.



Mesh - Teil | Part 2/6

Bestellnr. / Item no. Artikel / Article	 800001 Weiß	 405161 Colours Mountain	 405152 Colours Aqua	 405153 Colours Cream	 800001 Weiß	 405161 Colours Mountain	 405152 Colours Aqua	 405153 Colours Cream
11770 - 10855 Teller flach rund 15 cm Plate flat round 6 inch								
11770 - 10857 Teller flach rund 17 cm Plate flat round 6 2/3 inch		-	-	-				
11770 - 10859 Teller flach rund 19 cm Plate flat round 7 1/2 inch		-	-	-				
11770 - 10861 Teller flach rund 21 cm Plate flat round 8 1/4 inch						-	-	-
11770 - 10864 Teller flach rund 24 cm Plate flat round 9 1/2 inch								
11770 - 10867 Teller flach rund 27 cm Plate flat round 10 5/8 inch								
11770 - 10870 Teller flach rund 30 cm Plate flat round 11 3/4 inch								
11770 - 10873 Teller flach rund 33 cm Plate flat round 13 inch		-	-	-				



Spülmaschinenfest
Dishwasher safe



Mikrowellene geeignet
Microwave safe



Mesh - Teil | Part 3/6

Bestellnr. / Item no.	800001 Weiß	405161 Colours Mountain	405152 Colours Aqua	405153 Colours Cream	Bestellnr. / Item no.	800001 Weiß	405161 Colours Mountain	405152 Colours Aqua	405153 Colours Cream
Artikel / Article									
11770 - 16169 Teller flach quadratisch Plate flat square 9x9 cm 3 1/2x3 1/2 inch		-	-	-	11770 - 15299 1,30 l 44 oz Schale 18 cm Bowl 7 1/8 inch Höhe 9 cm Hight 3 1/2 inch				
11770 - 16174 Teller flach quadratisch Plate flat square 14x14 cm 5 1/2x5 1/2 inch		-	-	-	11770 - 15206 0,04 l 1 3/8 oz Universalschälchen 6 cm Multipurpose bowl 2 1/3 inch				
11770 - 16177 Teller flach quadratisch Plate flat square 17x17 cm 6 2/3x6 2/3 inch		-	-	-	11770 - 15454 0,55 l 18 2/3 oz Schale 14 cm Bowl 5 1/2 inch				
11770 - 16182 Teller flach quadratisch Plate flat square 22x22 cm 8 2/3x8 2/3 inch		-	-	-	11770 - 13324 2,30 l 78 oz Schüssel 24 cm Bowl 9 1/2 inch				
11770 - 16187 Teller flach quadratisch Plate flat square 27x27 cm 10 5/8x10 5/8 inch		-	-	-	11770 - 15751 0,30 l 10 oz Schüssel oval 16x12 cm Bowl oval 6 1/4x4 3/4 inch				
11770 - 16191 Teller flach quadratisch Plate flat square 31x31 cm 12 1/4x12 1/4 inch		-	-	-	11770 - 15752 0,68 l 23 oz Schüssel oval 20x15 cm Bowl oval 7 7/8x5 7/8 inch				
11770 - 16510 Teller tief quadratisch Deep square plate 20x20 cm 7 7/8x7 7/8 inch		-	-	-	11770 - 15296 1,20 l 40 1/2 oz Schüssel oval 25x18 cm Bowl oval 9 7/8x7 1/8 inch		-	-	-
11770 - 10422 0,30 l 10 1/8 oz Suppen-Obertasse Soup cup		-	-	-	11770 - 15290 Schale rund flach 12 cm Bowl round flat 4 3/4 inch				
11770 - 10421 Untertasse 18 cm Saucer 7 inch		-	-	-	11770 - 15291 Schale rund tief 14 cm Bowl round deep 5 1/2 inch				



Spülmaschinenfest
Dishwasher safe



Mikrowellene geeignet
Microwave safe



Mesh - Teil | Part 4/6

Bestellnr. / Item no. Artikel / Article	 800001 Weiß	 405161 Colours Mountain	 405152 Colours Aqua	 405153 Colours Cream	 800001 Weiß	 405161 Colours Mountain	 405152 Colours Aqua	 405153 Colours Cream	
11770 - 15289 Schale rechteckig 10x7 cm Bowl rectangular 4x2 3/4 inch					11770 - 12718 Platte flach oval 18x12 cm Platter flat oval 7x4 3/4 inch				
11770 - 15288 Schale quadratisch 10x10 cm Bowl square 4x4 inch					11770 - 12725 Platte flach oval 25x17 cm Platter flat oval 9 7/8x6 2/3 inch				
11770 - 15287 Schale rechteckig 20x10 cm Bowl rectangular 7 7/8x4 inch					11770 - 12730 Platte flach oval 30x21 cm Platter flat oval 11 3/4x8 1/4 inch				
11770 - 12380 Teller/Platte flach rechteckig (ohne Relief) 24x15 cm Plate flat rectangular (without relief) 9 1/2x6 inch		-	-	-	11770 - 12734 Platte flach oval 34x24 cm Platter flat oval 13 1/2x9 1/2 inch				
11770 - 12379 Teller/Platte flach rechteckig (ohne Relief) 26x24 cm Plate flat rectangular (without relief) 10 1/4x9 1/2 inch		-	-	-	11770 - 12738 Platte flach oval 38x26 cm Platter flat oval 15x10 1/4 inch				
11770 - 12381 Teller/Platte flach rechteckig (ohne Relief) 41x15 cm Plate flat rectangular (without relief) 16 1/8x6 inch		-	-	-	11770 - 12742 Platte flach oval 42x29 cm Platter flat oval 16 1/2x11 3/8 inch		-	-	-
11770 - 12382 Platte flach rechteckig 18x13 cm Platter flat rectangular 7x5 1/2 inch		-	-	-					
11770 - 12383 Platte flach rechteckig 26x13 cm Platter flat rectangular 10 1/4x5 1/2 inch									
11770 - 12384 Platte flach rechteckig 34x13 cm Platter flat rectangular 13 1/2x5 1/2 inch									




Spülmaschinenfest
Dishwasher safe



Mikrowellengeeignet
Microwave safe



Mesh - Teil | Part 5/6

Bestellnr. / Item no. Artikel / Article	 800001 Weiß	 405161 Colours Mountain	 405152 Colours Aqua	 405153 Colours Cream	 800001 Weiß	 405161 Colours Mountain	 405152 Colours Aqua	 405153 Colours Cream	
11770 - 14717 0,08 l 2 7/8 oz Obertasse Cup					11770 - 14345 Zuckerdosen-Deckel 10 cm Sugar bowl lid 4 inch				
11770 - 34607 0,09 l 3 oz Obertasse nieder Cup low		-	-	-	11770 - 14344 0,22 l 7 3/4 oz Zuckerdose Unterteil Sugar bowl base				
11770 - 14716 Untertasse 12 cm Saucer 4 3/4 inch									
11770 - 14742 0,18 l 6 1/3 oz Obertasse Cup					11770 - 14440 0,15 l 5 1/4 oz Gießer Creamer				
11770 - 14642 0,22 l 7 3/4 oz Obertasse Cup					11770 - 34002 Kaffeekannen-Deckel Lid for coffee pot		-	-	-
11770 - 14772 0,29 l 10 oz Obertasse Cup					11770 - 34001 0,30 l 10 1/2 oz Kaffeekannen-Unterteil Base for coffee pot		-	-	-
11770 - 15505 0,35 l 12 1/3 oz Becher mit Henkel Mug with handle					11770 - 34212 Teekannen-Deckel Lid for teapot		-	-	-
11770 - 14741 Untertasse 16 cm Saucer 6 1/4 inch					11770 - 34211 0,40 l 14 oz Teekannen-Unterteil Base for teapot		-	-	-



Spülmaschinenfest
Dishwasher safe



Mikrowellene geeignet
Microwave safe

